







# SMA COAXIAL CONNECTORS & ADAPTORS



## ADAPTORS

<p><b>Adaptor Plug To Plug</b></p>  <p><b>SMA-2500</b></p>	<p><b>Adaptor Plug To Jack</b></p>  <p><b>SMA-2510</b></p>	<p><b>Adaptor SMA J-P-J Tee</b></p>  <p><b>SMA-2594</b></p>	<p><b>Adaptor Plug To Jack, Right Angle</b></p>  <p><b>SMA-2599</b></p>
<p><b>Adaptor Jack To Jack</b></p>  <p><b>SMA-2700</b></p>	<p><b>Adaptor Jack To Jack, Bulkhead Feedthrough</b></p>  <p><b>SMA-2711</b></p>	<p><b>Adaptor SMA J-J-J Tee</b></p>  <p><b>SMA-2775</b></p>	<p><b>Dust Cap For Jack</b></p>  <p><b>SMA-DSTCP-P</b></p>

## JACKS

<p><b>Bulkhead Jack Receptacle</b></p>  <p><b>SMA-2761</b></p>	<p><b>Bulkhead Jack Receptacle</b></p> <p>Front Mount</p>  <p><b>SMA-2762</b></p>	<p><b>Panel Mount Jack Receptacle 4 Hole Sq.</b></p>  <p><b>SMA-2730</b></p>
<p><b>Panel Mount Jack Receptacle</b></p> <p>2-φ 2.6</p>  <p><b>SMA-2735</b></p>	<p><b>P.C. Board Straight Jack</b></p>  <p><b>SMA-2770</b></p>	<p><b>P.C. Board Right Angle Jack</b></p>  <p><b>SMA-2779</b></p>

### SMA Female Adaptors (RFA Series)

RFA-8181 SMA (F)-UHF (F)	RFA-8481 SMA (F)-TNC (F)
RFA-8183 SMA (F)-UHF (M)	RFA-8483 SMA (F)-TNC (M)
RFA-8281 SMA (F)-MU (F)	RFA-8681 SMA (F)-N (F)
RFA-8283 SMA (F)-MU (M)	RFA-8681T SMA (F)-N (F) Teflon
RFA-8381 SMA (F)-BNC (F)	RFA-8683 SMA (F)-N (M)
RFA-8383 SMA (F)-BNC (M)	RFA-8683T SMA (F)-N (M) Teflon

### SMA Male Adaptors (RFA Series)

RFA-8182 SMA (M)-UHF (F)	RFA-8482 SMA (M)-TNC (F)
RFA-8184 SMA (M)-UHF (M)	RFA-8484 SMA (M)-TNC (M)
RFA-8282 SMA (M)-MU (F)	RFA-8584 SMA (M)-FME (M)
RFA-8284 SMA (M)-MU (M)	RFA-8682 SMA (M)-N (F)
RFA-8382 SMA (M)-BNC (F)	RFA-8682T SMA (M)-N (F) Teflon
RFA-8384 SMA (M)-BNC (M)	RFA-8684 SMA (M)-N (M)
	RFA-8684T SMA (M)-N (M) Teflon