


# CELLULAR PLUG-IN ELIMINATORS/CHARGERS



PART NO.	FITS
<b>AT&amp;T</b>	
CEL-19CC	3610
CEL-25CC	3810
CEL-30CC	3710
CEL-39CC	3630
CEL-45CC	3760
CEL-65CC	3770
CEL-69CC	3625
<b>AUDIOVOX</b>	
CEL-2CC	MXV525
CEL-3CC	MXV800
CEL-4CC	MXV300
CEL-54CC	MXV440
CEL-60CC	MXV405
CEL-62CC	MXV400
CEL-72CC	CDM4000
CEL-84CC	CDM1100
CEL-96CC	CDM120
CEL-97CC	CDM1000
CEL-98CC	CDM3500
CEL-115CC	CDM9100
CEL-3000CCBK	CDM3000
CEL-3000CCBM	CDM3000

PART NO.	FITS
<b>ERICSSON</b>	
CEL-11CC	HOTLINE
CEL-12CC	200/300 SERIES
CEL-49CC	600/700 SERIES
CEL-100CC	T-28
<b>FUJITSU</b>	
CEL-10CC	PCX
CEL-69CC	PCZ
<b>HYUNDAI</b>	
CEL-73CC	110
<b>JRC</b>	
CEL-28CC	PTR-825
CEL-29CC	PTR-800
CEL-39CC	PTR-850
<b>LUCKY GOLDSTAR</b>	
CEL-70CC	LG300
CEL-89CC	LG330W
CEL-120CC	V111
<b>mitsubishi</b>	
CEL-17CC	4000/4500
CEL-18CC	AH-129
CEL-54CC	T200
CEL-90CC	G310

PART NO.	FITS
<b>MOTOROLA</b>	
CEL-5CC	FLIP
CEL-5ELCC	ELITE
CEL-41CC	STARTAC
CEL-60CC	POPULOUS
CEL-75CC	SC3160
CEL-86CC	VPHONE
CEL-94CC	V120
CEL-95CC	V60
CEL-121CC	D520
CEL-650CC	PIPER
CEL-TCC	TALKABOUT
COM-8971CC	M3090
<b>NEC</b>	
CEL-19CC	P100/110
CEL-21CC	P400/600
CEL-23CC	P700/800
CEL-61CC	MAX960
CEL-103CC	2600
<b>NEXTEL</b>	
CEL-94CC	i50 / i90
COM-8100CC	i280/i600 i390
COM-8615CC	i1000
COM-8971CC	i500 / i700
<b>NOKIA</b>	
CEL-25CC	100/101/2120/232
CEL-46CC	636/918
CEL-57CC	5100/6100/3390
CEL-57CC	7110/8260/8810

NOTE: ADD "P" TO PART NUMBER FOR RETAIL PACKAGING

# CELLULAR PLUG-IN ELIMINATORS/CHARGERS

PART NO.	FITS
<b>OKI</b>	
CEL-30CC	900/910
CEL-40CC	1325/1410
CEL-45CC	1145/1150
<b>PANASONIC</b>	
CEL-33CC	EBH-30
CEL-34CC	EBH-40/50
CEL-51CC	EBH-63/64/65/66
CEL-52CC	EBH-10/20
CEL-114CC	TX210
<b>QUALCOMM</b>	
CEL-56CC	800/1900
CEL-63CC	820/1920/2700
CEL-66CC	QPHONE
CEL-68CC	860/1960/2760
CEL-88CC	Q2035/2230
CEL-113CC	Q3035/6065

PART NO.	FITS
<b>SAMSUNG</b>	
CEL-55CC	SCH1900/1910
CEL-67CC	SCH2000/2010
CEL-71CC	1500/1510/1530
CEL-78CC	SPH-10
CEL-87CC	411/811/2500
CEL-123CC	T100
<b>SANYO</b>	
CEL-77CC	SCP-3000/4000/4500
<b>SONY</b>	
CEL-8CC	CH-444/777/888
CEL-56CC	500/600/800/900
CEL-63CC	1200/2200/3200

PART NO.	FITS
<b>TECHNOPHONE</b>	
CEL-25CC	405/415/EZ400/815
<b>TOSHIBA</b>	
CEL-53CC	TCP900/1000
<b>UNIDEN</b>	
CEL-35CC	CP4600/4900
CEL-36CC	CP5500
CEL-37CC	CP5600/6600
CEL-111CC	PCD1000/2000
CEL-112CC	MINI 200

# CELLULAR DESK TOP CHARGER

PART NO.	FITS
<b>AUDIOVOX</b>	
CELCHG-2	AUDIOVOX MVX525
CELCHG-44	AUDIOVOX MVX 401/501
CELCHG-54	AUDIOVOX MVX 440
<b>ERICSSON</b>	
CELCHG-12	ERICSSON 200/300 SERIES
CELCHG-47	ERICSSON 700 SERIES

PART NO.	FITS
<b>MOTOROLA</b>	
CELCHG-5	MOTOROLA FLIP PHONE
CELCHG-41	MOTOROLA STARTAC
<b>NEXTEL</b>	
COM-8615DKCHG	NEXTEL i1000
COM-8971DKCHG	NEXTEL i500

PART NO.	FITS
<b>NOKIA</b>	
CELCHG-24	NOKIA 100
CELCHG-25	NOKIA 101
CELCHG-27	NOKIA 232/239
CELCHG-38	NOKIA 2100 SERIES
CELCHG-42	NOKIA 636
CELCHG-46	NOKIA 918
CELCHG-57	NOKIA 5100/6100 SERIES
CELCHG-59	NOKIA 252

NOTE: ADD "P" TO PART NUMBER FOR RETAIL PACKAGING